

FIG. 1




FIG. 2

+




FIG. 3

+




FIG. 4




FIG. 5

+




FIG. 6

Replacement Sheet




FIG. 7




FIG. 8






FIG. 9

APC Back-UPS HS 500 - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://169.215.32.160/

APC Back-UPS HS 500

APC Back-UPS HS 5

Logoff

Status Configuration Maintenance About

Battery Self Test

Test Now 90

Test results are displayed on the status page.

Update Battery Replacement Date

Update Now 92

Perform this operation only upon battery replacement.

Change Username and Password

Enter New Username

Enter New Password

Valid entries are 20 or lower characters in length.

Update Now

Restore Factory Defaults

Restore Now 94

Restore battery backup settings back to their factory default values.

Maintenance Page

Maintenance Page

Internet

FIG. 10




FIG. 11




FIG. 12




FIG. 13